

TNIAMP Phase I-IV (47 Sub Basins) Andhra Pradesh



I Phase

- 1 Cauvery Delta
- 2 Gadanadhi
- 3 Kallar
- 4 Kousiganadhi
- 5 Krishnagiri to Pambar
- 6 Lower Bhavani
- 7 Lower Palar
- 8 Lower Tamiraparani
- 9 Lower Vaigai
- 10 Lower Vellar
- 11 Manjalar
- 12 Nagariyar
- 13 Ponnaiyar
- 14 Sathaiyar
- 15 Sirumalaiyar
- 16 Suruliyar
- 17 Upper Bhavani
- 18 Varahanadhi

II Phase

- 19 Agaramar
- 20 Aiyar
- 21 Aliyar (Pennaiyar)
- 22 Vaniyar
- 23 Pambar
- 24 Chittar (Tamirabharani)
- 25 Karaipottanar
- 26 Lower Coleroon
- 27 Lower Pennaiyar
- 28 Mettur Reservoir
Noyal Confluence
- 29 Nandhiyar
- 30 Pachiyar
- 31 Pungar
- 32 Thirumanimuthar
- 33 Uppar
- 34 Nandhiyar Kulaiyar

III Phase

- 35 Cheyyar
- 36 Chinnar
- 37 Gummidipoondi
- 38 Manimukdhanadhi
- 39 Musukundanadhi
- 40 Paravanar
- 41 Vegavati
- 42 Marudaiyar
- 43 Nambiyar

IV Phase (IAMWARM)

Legend

- River
- I Phase
- II Phase
- III Phase
- IV Phases

- 44 Aliyar
- 45 Therkkar
- 46 Ponnai
- 47 Thurinjalar

Scale

