


Koraiporattanar Sub Basin

VELLAR BASIN



11°20'0"N

11°20'0"N

Pudhuchattram

Sendamangalam

Kolli Hills

Thirumanimuthar Sub Basin

Namakkal

11°10'0"N

11°10'0"N

Aiyar Sub Basin

Mohanur

Erumaipatti

Legend

Amaravathai Sub Basin

- Drainage
- River
- Canal
- Tanks
- Namakkal (Villages)
- Trichy (Villages)

Thathangar pettai

Thottiyam

11°00'0"N

11°00'0"N

Uppar Sub Basin

Pungar Sub Basin

Scale



78°0'0"E

78°10'0"E

78°20'0"E

78°30'0"E

78°40'0"E