

78°30'0"E

78°40'0"E

78°50'0"E

79°0'0"E

79°10'0"E

VELLAR BASIN

Nandhiyar Kulaiyar Sub Basin Drainage Map



Marudhaiyar Sub Basin

11°10'0"N


11°10'0"N

11°00'0"N

11°00'0"N

10°50'0"N

10°50'0"N



Aiyaar
Sub Basin

Legend

- PWD Tanks
- Drainage
- River
- Canal
- Tanks
- Trichy (Villages)
- Perambalur (Villages)

Pambar to Thirukovilar Sub Basin

CAUVERY DELTA

Scale



78°30'0"E

78°40'0"E

78°50'0"E

79°0'0"E

79°10'0"E